Limit switch board • up to 12.1997



Designation	Part no.	
Limit switch board, dublex with terminals 6 micro	40009596	

Emergency manual operator, with mounting accessories Enquire. in the case of: motors with a fan and cover or ELEKTROMATEN with built on brake, ATEX

NHK "Hand Crank" • from 1995 onwards

	Designation		Part no.
	Hand crank switch	Ø 10 mm Ø 12 mm	20002862.00001 20002862.00011
Z	Hand crank NHK	Ø 10 mm Ø 12 mm	30002591 30002749
Z	Hand crank with knuckle joint NHKK	Ø 10 mm Ø 12 mm	30002715 30002750

SK "Rapid hand chain operator" • up to 04.2002



Designation	Part no.
Rapid hand chain operator SK (Hand chain 4 m, 0.5 m engaging and disengaging cord)	30004272.00004

KNH "Hand chain operator" • from 1997 onwards

Designation	Part no.
KNH25 KNH60 (replacement for KNH50) Hand chain 4 m, 0.5 m engaging and disengaging cord	20002862.0003 20002862.0004



Spare parts and analysis tools

Door controls

Service case

The GfA service case allows the efficient and cost-effective fault analysis on site.



De	signation	Description		Part no.	
	rvice case ntent → 1	Documentation -c Documentation -f Documentation -r	res	sit- 20004007	.00002
No.	Designation		No.	Designation	
1.	Case	۵	10.	Rubber profile OSE 0.2 m	
2.	GfA-Stick	8	11.	Connection cable 6.5 m for OSE	J
3.	Voltcraft digital multimeter	Θ	12.	Rectifier EGR II	()
4.	Door control TS 971 (for hard wir	ing) 🕕	13.	Resistor 8k2	
5.	WSD door module with battery		14.	Operating and installation instructions	
6.	Spiral cable with junction box	6		(e.g. for TS 970, TS 971, WSD)	
7.	Digital limit switch DES 4	G	15.	Additional documents for	
8.	Universele OSE-set 0.5 m	0		structured fault diagnostics	
9.	OSE tester	0			



Door controls • up to year 2006



Reversing contactor control WS 900





Spare parts Door controls (TS-A housing)

Door controls: TS 956/TS 958/TS 961/TS 970 • up to year 2013/TS 981



Designation	Description	Part no.
TS 981 board	Within cover	30004613
Housing 2+3+6+7 TS-A1 cpl.	Top section with screws, keyboard, hinges, bottom section	20002984.00001
Housing TS-A2 cpl. "orange"	Top section with screws, keyboard, hinges, bottom section	20002984.10002
Top section of housing 2+3+6 TS-A1 cpl.	Top section with screws, keyboard, hinges	20002985.00001
Top section of housing 4+5+6 TS-A2 cpl. "orange"	Top section with screws, keyboard, hinges	20002985.10002
Keyboard for TS-A1 3	With mounting material	30004638
Keyboard for TS-A2 "orange" 5	With mounting material	30005064
Hinge TS-A 6	2 pc	30004632
Bottom section of housing TS-A 🕜		40014770
Mains switch 8	For TS 956, TS 958, TS 961, TS 970; 4-pole	40015183

Door control: TS 981-XL



Designation		Description	Part no.
Mounting kit for housing XL	0	4 pc	40017128
Membrane push button for TS-A	2	With viewing window	40016547
Hinge	3	2 рс	30005828
Housing XL for TS-A	8+4 +5	Consits of: Hinge, cover, bottom section with mounting plate and 3 DIN mounting rails	30005246
TS 981 board	0	Within cover	30004613
Mains switch for housing XL	0	4-pole	40015183
Housing XL for TS-A with mains switch, complete	1 + 2 +3+ 4 +5+7	Consits of: Mounting kit for housing XL, Membrane push button for TS-A, Housing XL for TS-A, mains switch for housing XL	20002984.20006
Lock for padlock	8	2 pc (without padlock)	40019408

Door controls: TS 959/TS 970/TS 971 • from year 2012



Designation		Description	Part no.
TS 959 board 1 TS 970 board TS 971 board (350 mA) TS 971 board (1000 mA)		Within cover incl. keyboard Within cover incl. keyboard Within cover incl. keyboard Within cover incl. keyboard	30005241.00001 30005273.00001 30005070.00001 30005070.00012
Bottom section of housing - for TS 959 / TS 970 - for TS 971	TS-B 2	For installation of the TS-board	40019859 40019858
Cover kit TS-B1	3+4+6	Consists of: small cover, large cover	30005192.00001
Cover kit TS-B1 for mains switch	3+5+6	Consists of: small cover, large cover, prepared for mains switch	30005192.00006
Spacer foot TS-B	6	4 рс	40016530

Door controls: TS 970-XL/TS 971-XL • from year 2012

	Designation
	Mounting housing X
	Membrand for TS-B
······································	Hinge
	Top sectio of housing
	Housing X
1	TS 970 bos TS 971 bos TS 971 bos
	Mounting Mounting
8 0	Connectio when harc
۵ 🚸	TS 970 for c TS 971 for c
	Mains swi housing X
	Housing X with main complete
	Lock for p

Designation	Description	Part no.
Mounting kit for 1 housing XL	4 pc	40017128
Membrane push button 2 for TS-B	With viewing window	30005408
Hinge 3	2 рс	30005828
Top section 2+3+4 of housing XL for TS-B	Consists of: Membrane push button for TS-B, hinge, cover	30005827.00001
Housing XL for TS-B 3+4+5	Consits of: Hinge, cover, bottom section with mounting plate and 3 DIN mounting rails	30005126
TS 970 board 6 TS 971 board (350 mA) TS 971 board (1000 mA)	Within cover incl. keyboard Within cover incl. keyboard Within cover incl. keyboard	30005273.0000 30005070.0000 30005070.00012
Mounting adapter TS-B TS 970 🤫 Mounting adapter TS-B TS 971	For installation of the TS-board For installation of the TS-board	40019862 40019861
Connection kit, 3+9 when hardwired	Consists of: Mains supply terminal and slide gland	30005132.00001
TS 970 for control enclosure installation TS 971 for control enclosure installation	(350 mA) Consists of: Board, mounting adapter TS-B, mains supply terminal	30005405 30005406
Mains switch for 🕕 🕕	4-pole	40015183
Housing XL for TS-B 1+2+3+ with mains switch, 2+5+7+ complete 1	Consits of: Mounting kit for housing XL, Membrane push button for TS-B, Housing XL for TS-B, Mounting adapter TS-B, mains switch for housing XL	20002984.2000
Lock for padlock 🕧	2 pc (without padlock)	40019408